

Mirror Demister installation instructions

Attaching to the Mirror

1. Mark out the **back** of the mirror to indicate where the demister pad is to be fitted
2. Peel off the protective paper exposing the 'sticky' side
3. Position one edge of the demister pad in the desired position on the mirror, keeping the other edge away from the mirror.
4. Gradually lower the pad onto the mirror applying even pressure to ensure that there are no air bubbles or creases formed.
5. If the mirror is not framed & is being fitted directly onto the wall, a small recess will need to be made in the wall to compensate for the cold cable connection & to allow the mirror to sit flush.

Electrical Connections

All wiring must conform to the latest IEE wiring regulations (BS7671 equivalent) if in doubt always consult a qualified electrician.

1. It is recommended that the demister pad is connected via the lighting circuit or on a separate switch.
2. The circuit should be protected by a 5amp fuse or circuit breaker
3. The wires are coloured as follows: **BLUE – Neutral**, and **BROWN – Live/phase**
4. The Demister pad must not be accessible once installed
5. Any metal part surrounding the mirror must be earthed & comply with current wiring regulations, this includes metallic mirror safety film (if used).
6. Multiple pads may be fitted to a single mirror & should be connected in parallel – **pads must not overlap**
7. Please check the resistance of the Mirror demister before and after attaching it to the wall or mirror. (please see readings bellow)

The demister pad must not be cut or pierced as this may damage the insulation making it unsafe

Mirror Code	Size mm	Reading +/- 10%
MH7010	252x274	4610 ohms
MH7020	574x274	1966 ohms
MH7030	519x524	1065 ohms
MH7035	812x524	688 ohms
MH7040	1004x524	557ohms
MH7050	1506x524	370 ohms

Please note mirrors with cut outs should not be used

Please Note : Mirrors with a foil backing or a metal frame may need to be earthed .